NETWORK DOCUMENTATION

RustDesk remote desktop

Desktop support on the Panel PC through the Rosepetal RustDesk server. Firewall requirements for customer IT.

SCOPE

Panel PC: RustDesk. Connections start from the installed equipment; allow the corresponding return traffic. No public inbound port forwarding.

IN THIS DOCUMENT

01 RustDesk on the Panel PC 02

01 / SUPPORT EGRESS

RustDesk on the Panel PC

Apply the service rule to the Panel PC, including the corresponding return traffic.



RUSTDESK / PANEL PC

Setting	Required value
Destination	89.60.167.50 (rustdesk.rosepetal.ai)
Direction	Outbound, allowing response traffic
TCP destination ports	21115, 21116, 21117
UDP destination port	21116

No inbound port forwarding

These are destination ports on the Rosepetal RustDesk server. The standard deployment runs RustDesk on the Panel PC. Cloudflare exposes Rosepetal web software only: desktop support uses RustDesk.

Full remote-access requirements: read the standard remote access guide